INSTRUCTIONS



Page 1 of 1

Instruction Sheet Number: 99TA526120D

Description: Replacement Thermistor Package

Author: Engineering Date: September 14, 2017

Part Number: 30GB-660---002--S

REPLACEMENT THERISTOR PACKAGE

Package Contents:

Sensor Assembly Part Number HH79NZ014
Coupling Assembly Part Number DC99RA025
Instruction Sheet Part Number 99TA526120
Connectors Part Number HY06AM016

CAUTION: Original Sensor Assembly is installed directly in refrigerant or

water circuit. Relieve all refrigerant pressure or drain water

before attempting to remove original sensor.

Assembly Procedure:


Remove and discard failed sensor and coupling.

2. Apply pipe sealant compound to 1/4" NPT threads of replacement coupling assembly and install in place of original.

NOTE: It is not necessary to disassemble coupling prior to installation.

CAUTION: To avoid damage to ferrules <u>DO NOT</u> use packing nut to tighten 1/4 NPT body in place.

3. Insert new sensor in coupling body to its full depth (Figure 1). Hand tighten packing nut OR nut & seal to position ferrules, then tighten another 1 1/2 turns using suitable tool.



4. Cut lead(s) to proper length and install new insulation displacement connectors.

Carrier EMEA Replacement Components Division, Route de Thil, 01120 Montluel France www.carrier-ercd.com