




**CODE: 33MC9001**

- GB** Installation instructions interface kit:  
- Zone Manager (DX systems)
- I** Istruzioni di installazione kit interfaccia :  
- Zone Manager (sistemi DX)


- F** Instruction d'installation du kit Interface :  
- Zone Manager (Systèmes DX)
- D** Anweisungen zur Installation des Interface-Bausatzes:  
- Zone Manager (System DX)
- E** Instrucciones de instalación para el interface:  
- Zone Manager (Sistemas DX)


**42VMC / 42VQV**





# 42VMC / 42VQV


4



5








6






# 40KMC / 40KQV







# 40KMC / 40KQV

6









7





# 40SMC / 40SQV / 40DMC / 40DQV





 United Technologies

Carrier EMEA Replacement Components Division, route de Thil, 01120 Montluel France  
[www.carrier-ercd.com](http://www.carrier-ercd.com)

Printed in France